


# Self-install Instructions

PureFiber-ADSL Failover (Upgrade from C-A-F) - Self Install Guide

Skyway West - Aug 2019



## Your current setup



This is what your service setup will look like immediately after Telus completes their PureFiber Installation

Please follow this guide to fully complete the installation of your connectivity solution.

**IMPORTANT:**  
You will lose connectivity during this process. Please proceed **ONLY** when it is okay to do so.

Please call Skyway West Support if you need assistance: 604-482-1212


# Don't forget to plug in!



All devices described within this guide must be plugged in to appropriate power outlets.


The diagrams herein do NOT show power cords in order to keep them simple and easy to understand.

Unplug cables as shown



1. Unplug the Fiber ONT from the WiFi Router
2. Unplug the Cable Modem and set aside

## Reconnect Cable modem and connect WiFi router



3. Connect the Fiber ONT (provided by Telus) into Port 1 of the RouterBoard Management Router

6. Connect the Actiontec WiFi router into Port 4 of the RouterBoard Management Router (optional)

**Please see port diagram**


7. Please call Skyway West Support at 604-482-1212 for testing and confirming the configuration

Set aside / return to Provider



Cable Modem

## Your Finished Setup



The **Actiontec T3200** WiFi router is configured for public WiFi. WiFi internet traffic is separated from LAN internet traffic; WiFi users cannot reach your LAN directly through our management router.

In order to reach your internal network, WiFi traffic is tunneled to Skyway and returns through your Internet connection to your LAN firewall.

If you prefer to not use the Actiontec WiFi router, please inform [provisioning@skywaywest.com](mailto:provisioning@skywaywest.com).

The public WiFi SSID and Password are written on the Actiontec WiFi router.